

OPERATING AND INSTALLATION MANUAL

INDIRECT HOT WATER TANKS

OKC 100 NTR
OKC 125 NTR
OKC 160 NTR
OKC 200 NTR
OKC 250 NTR
OKC 200 NTRR
OKC 250 NTRR

OKC 100 NTR/HV
OKC 125 NTR/HV
OKC 160 NTR/HV

OKC 80 NTR/Z
OKC 100 NTR/Z
OKC 125 NTR/Z
OKC 160 NTR/Z
OKC 200 NTR/Z



Družstevní závody Dražice - strojírna s.r.o.
Dražice 69, 294 71 Benátky nad Jizerou
tel.: +420 / 326 370 990
fax: +420 / 326 370 980
e-mail: prodej@dzd.cz

 **DRAŽICE**
ČLEN SKUPINY NIBE

CONTENTS

1	PRODUCT TECHNICAL SPECIFICATION.....	4
1.1	FUNCTION DESCRIPTION	4
1.2	ADVICE FOR CUSTOMERS	4
1.2.1	HOT WATER CONSUMPTION	4
1.2.2	ENERGY SAVING.....	4
1.2.3	EMERGENCY POWER CONSUMPTION	5
1.3	DESIGN AND GENERAL HEATER DIMENSIONS.....	6
2	OPERATION AND FITTING INSTRUCTIONS.....	16
2.1	OPERATING CONDITIONS	16
2.2	WALL MOUNTING.....	16
2.3	PLUMBING FIXTURE.....	17
2.4	CONNECTION OF INDIRECT TANK TO HOT WATER SYSTEM.....	21
2.5	ELECTRICAL INSTALLATION.....	21
2.5.1	GENERAL INFORMATION FOR ELECTRICAL INSTALLATION	21
2.5.2	ELECTRONIC THERMOSTAT WIRING METHODS	21
2.6	FIRST COMMISSIONING.....	22
2.7	PUTTING OUT OF SERVICE, DISCHARGE	23
2.8	INSPECTION, MAINTENANCE & CARE FOR THE APPLIANCE	23
2.9	MOST FREQUENT FUNCTION FAILURES AND THEIR CAUSES	24
3	OPERATION OF THERMOSTAT	25
3.1	SERVICING.....	25
3.1.1	OPERATING DEVICES OF THE TANK	25
3.1.2	TEMPERATURE SETTING	27
4	IMPORTANT NOTICES	28
4.1	INSTALLATION REGULATIONS.....	28
4.2	ACCESSORIES	28
4.3	TRANSPORT & STORAGE INSTRUCTIONS	28
4.4	DISPOSAL OF PACKAGING MATERIAL AND NON-FUNCTIONING PRODUCT.....	29

CAREFULLY READ THIS MANUAL BEFORE INSTALLING THE WATER HEATER!

Dear Customer,

The Works Cooperative of Dražice – Machine Plant, Ltd., would like to thank you for your decision to use a product of our brand. With this guide, we will introduce you to the use, construction, maintenance and other information on electrical water heaters.



The product is not intended to be controlled by

- a) people (including children) with reduced physical, sensual or mental capacities, or
- b) people with insufficient knowledge and experiences unless supervised by responsible person, or unless properly instructed by such responsible person.

The manufacturer reserves the right for engineering modification of the product. The product is designed for permanent contact with drinkable water.

It is recommended to use the product in indoor environment with air temperatures from +2°C to 45°C and a relative humidity up to 80%. 80%.

Product's reliability and safety is proven by tests implemented by the Engineering Test Institute in Brno.

Made in the Czech Republic.

Meaning of pictograms used in the Manual



Important information for heater users.



Abiding by the recommendations of the manufacturer serves to ensure trouble-free operation and the long service life of the product.



Caution!

Important notice to be observed.

1 PRODUCT TECHNICAL SPECIFICATION

1.1 FUNCTION DESCRIPTION

Indirect stationary NTR and NTRR series TANKS are used to prepare HSW in combination with another hot water supply, mostly gas boiler; in NTRR types in combination of two hot water sources (gas boiler + solar system, heat pump). Their nominal performance provides sufficient amount of hot service water (HSW) even for large flat units - premises, restaurants and similar establishments. **In case of increased hot water consumption, these tanks heat water continuously, operating similarly to flow heaters.**

Closing valves of the heat exchanger must be opened which ensures heating water flow from the hot water heating system. Together with closing valve, it is recommended to install an air outlet valve at the inlet to the heat exchanger in order to bleed the heat exchanger as needed, in particular before the beginning of the heating season (Figure 12, Figure 13, Figure 14, Figure 15 - by the type). The time it takes to heat up using the heat exchanger depends on the temperature and flow of water in the hot water heating system. A suspended tank is made in a universal design – depending on the need of connecting the closing valves to the heating element either from the right, or from the left.

1.2 ADVICE FOR CUSTOMERS

1.2.1 HOT WATER CONSUMPTION



Consumption of hot water in households depends on the number of people, amount of sanitary equipment, length, diameter and insulation of piping in the flat, or on individual habits of users. The cheapest option of water heating comes at the time when the electricity rate is reduced.

1.2.2 ENERGY SAVING



Hot utility water reservoir is insulated by means of top-quality polyurethane foam with zero CFCs content. Adjust the temperature of the heater's thermostat to that level only that you need to run your home. Thus you will reduce electricity consumption, as well as the amount of lime sediments on the walls of the receptacle and on the heat exchanger.

Benefits of using indirect heater:

- installation and connection to hot water supply,
- very fast hot utility water heating,
- enamelled steel tank ensures compliance with all hygienic requirements for the quality of HUW,
- integrated protective magnesium anode increases corrosion resistance,
- quality polyurethane insulation ensures minimum heat losses,

- smoothly settable HUW temperature up to 74°C,
- multiple supply points,
- in types with two exchangers, possibility of using two hot water supplies or, via a combination of those, obtain double heat-transfer surface,
- light indication of the heater's run,
- HSW temperature control,
- possibility of connecting HUW circulation.

1.2.3 EMERGENCY POWER CONSUMPTION



If no heated water is taken from the tank, a small amount of heat leaks. This loss is measured for a period of 24 hours at the temperature of 65°C in the heater, and at 20°C in its ambient area. The resulting value is expressed in units [kWh/24h] and indicates the amount of power needed to maintain the set temperature. Data sheet - see Table 1.

TYPE	Heating water flow (l/h)	Pressure loss (mbar)	HEAT LOSS [kWh/24h]
OKC 100 NTR	720	33	0,9
OKC 125 NTR		46	1,05
OKC 160 NTR		46	1,4
OKC 200 NTR		46	1,8
OKC 250 NTR		46	2,1
OKC 200 NTRR		2 x 33	1,8
OKC 250 NTRR		2 x 33	2,1

Table 1

1.3 DESIGN AND GENERAL HEATER DIMENSIONS

The tank receptacle is made of steel plate and tested at 0.9 MPa of overpressure. The inside of the receptacle is enamelled. A flange is welded onto the lower bottom of the receptacle with a flange lid screwed onto it. A sealing ring is inserted between the flange lid and the flange. Thermowells for thermostat sensors and thermometer installation are placed in the flange lid. An anode rod is mounted onto the M8 nut. **The water reservoir is insulated by means of polyurethane foam.** Electric wiring is placed underneath the plastic removable cover. The temperature of water can be set using the thermostat. Heat exchanger(s) is/are welded onto the pressure tank.

Description of basic parts of the tank – by individual types (Figure 1, Figure 2, Figure 3)

Heater dimensions - (Figure 4, Figure 5, Figure 6, Figure 7, Figure 8, Figure 9) and (Table 2, Table 3, Table 5, Table 7, Table 8).

Technical description: OKC 100 NTR, OKC 125 NTR, OKC 160 NTR, OKC 200 NTR, OKC 250 NTR, OKC 200 NTRR, OKC 250 NTRR




Figure 1

Technical description: OKC 100 NTR/HV, OKC 125 NTR/HV, OKC 160 NTR/HV




Figure 2

Technical description: OKC 80 NTR/Z, OKC 100 NTR/Z, OKC 125 NTR/Z, OKC 160 NTR/Z, OKC 200 NTR/Z




Figure 3

OKC 100 NTR, OKC 125 NTR, OKC 160 NTR




Figure 4

	OKC 100 NTR	OKC 125 NTR	OKC 160 NTR
A	902	1067	1255
B	891*	1058*	1249*
C	147	147	147
D	524	524	524
E	197	197	197
F	637	767	767
L	537	637	897
M	-	-	-
N	-	-	-
O	-	-	-

neck # 1	3/4" outer
neck # 2	1" outer
neck # 3	3/4" inner
neck # 4	1/2" inner

*Height from the upper heater's edge to the end of the water inlet and outlet tubes.

Table 2

OKC 200 NTR, OKC 250 NTR, OKC 200 NTRR, OKC 250 NTRR




Figure 5

	OKC 200 NTR	OKC 200 NTRR	OKC 250 NTR	OKC 250 NTRR
A	1398	1398	1578	1578
B	603	603	603	603
C	80	80	80	80
D	585	585	585	585
E	210	210	210	210
F	780	650	780	650
L	950	950	1060	1060
M	-	710	-	890
N	-	1150	-	1330
O	1280	1280	1460	1460

neck # 1	3/4" outer
neck # 2	1" outer
neck # 3	3/4" inner


*Height from the upper heater's edge to the end of the water inlet and outlet tubes.

Table 3

TYPE		OKC 100 NTR	OKC 125 NTR	OKC 160 NTR	OKC 200 NTR	OKC 200 NTRR	OKC 250 NTR	OKC 250 NTRR
VOLUME	L	87	112	148	208	200	242	234
MAX OPERATING OVERPRESSURE IN THE TANK	MPa				0,6			
MAX OPERATING OVERPRESSURE IN THE EXCHANGER	MPa				1			
ELECTRICAL CONNECTION OF CONTROL ELEMENTS					1 PE-N 230V/50Hz			
EL. PROTECTION					IP 42			
MAX TEMPERATURE HSW	°C				90			
RECOMMENDED HSW TEMPERATURE	°C				60			
MAX WEIGHT OF THE HEATER WITHOUT WATER	kg	53	66	73	93	102	95	104
EXCHANGER HEAT TRANSFER SURFACE	m ²	1,08	1,45	1,45	1,45	2 x 1	1,45	2x 1
RATED THERMAL OUTPUT AT HEATING WATER TEMPERATURE OF 80°C AND FLOW 720 L/H	W	24000	32000	32000	32000	2 x 24000	32000	2 x 24000
TIME OF HEATING BY EXCHANGER FROM 10°C TO 60°C	min	13	12	16	23	14 / 14	26	14 / 23
STATIC LOSS	W	42	54	75	82	82	87	87

Table 4

OKC 100 NTR/HV, OKC 125 NTR/HV, OKC 160 NTR/HV



neck # 1	3/4" outer
neck # 2	3/4" outer
neck # 3	3/4" outer
neck # 4	3/4" outer
neck # 5	3/4" outer
neck # 6	1/2" inner




Figure 6

TYP	OKC 100 NTR/HV	OKC 125 NTR/HV	OKC 160 NTR/HV
A	902	1067	1092
B*	893	1058	1079
C	144	144	146
D	524	524	584
E	165	165	165
F	119	119	119
G	182	182	182

*Height from the upper heater's edge to the end of the water inlet and outlet tubes.

Table 5

TYPE		OKC 100 NTR/HV	OKC 125 NTR/HV	OKC 160 NTR/HV
VOLUME	L	87	113	144
MAX OPERATING OVERPRESSURE IN THE TANK	MPa		0,6	
MAX OPERATING OVERPRESSURE IN THE EXCHANGER	MPa		1	
ELECTRICAL CONNECTION OF CONTROL ELEMENTS		1 PE-N 230 V/50Hz		
EL. PROTECTION			IP 42	
MAX TEMPERATURE HSW	°C		90	
RECOMMENDED HUW TEMPERATURE	°C		60	
MAX WEIGHT OF THE HEATER WITHOUT WATER	kg	53	64	77
EXCHANGER HEAT TRANSFER SURFACE	m ²	1,08	1,45	1,45
RATED THERMAL OUTPUT AT HEATING WATER TEMPERATURE 80°C AND FLOW 720 l/h	W	24000	32000	32000
TIME OF HEATING BY EXCHANGER FROM 10°C TO 60°C	min	13	12	16
STATIC LOSS	W	42	65	65

Table 6

OKC 80 NTR/Z, OKC 100 NTR/Z, OKC 125 NTR/Z




Figure 7

①	3/4" outer
②	1" outer
③	3/4" inner

* in OKC 80 NTR/Z ② - 3/4" outer

TYPE	OKC 80 NTR/Z	OKC 100 NTR/Z	OKC 125 NTR/Z
A	757	902	1066
B*	748	893	1057
C	615	632	797
D	524	524	524
F	70	70	70
G	172	172	172
H	501	703	703
I	211	263	263
J	-	553	553
R	450	450	450

Table 7

OKC 160 NTR/Z





Figure 8

①	3/4" outer
②	1" outer
③	3/4" inner



TYPE	OKC 160 NTR/Z	OKC 200 NTR/Z
A	1255	1290
B*	1246	1277
C	1001	796
D	524	584
E	186	196
F	70	70
G	172	172
H	703	679
I	263	239
J	833	889
R	450	450

OKC 200 NTR/Z





Figure 9

Table 8



TYPE		OKC 80 NTR/Z	OKC 100 NTR/Z	OKC 125 NTR/Z	OKC 160 NTR/Z	OKC 200 NTR/Z
VOLUME	L	76	95	120	148	196
MAX OPERATING OVERPRESSURE IN THE TANK	MPa			0,6		
MAX OPERATING OVERPRESSURE IN THE EXCHANGER	MPa			1		
ELECTRICAL CONNECTION OF CONTROL ELEMENTS				1 PE-N 230V/50Hz		
EL. PROTECTION				IP 44		
MAX TEMPERATURE HSW	°C			90		
RECOMMENDED HSW TEMPERATURE	°C			60		
HEIGHT OF THE HEATER	mm	757	902	1067	1255	1287
DIAMETER OF THE HEATER	mm	524	524	524	524	584
MAX WEIGHT OF THE HEATER WITHOUT WATER	kg	38	56	61	70	84
EXCHANGER HEAT TRANSFER SURFACE	m ²	0,41	1,08	1,08	1,08	1,08
RATED THERMAL OUTPUT AT HEATING WATER TEMPERATURE 80°C AND FLOW 720 l/h	W	9000	24000	24000	24000	24000
TIME OF HEATING BY EXCHANGER FROM 10°C TO 60°C	min	29	14	17	22	28
STATIC LOSS	W	40	47	57	67	72

Table 9

2 OPERATION AND FITTING INSTRUCTIONS

2.1 OPERATING CONDITIONS



The tank shall only be used in accordance with the conditions specified on the power plate and in instructions for electric wiring. Besides the legally acknowledged national regulations and standards, also conditions for connection defined in the local electric and water works have to be adhered to, as well as the installation and operation manual. The room, in which the appliance will be operated, must be frost-free. The appliance has to be mounted at a convenient place; it means that the appliance must be easily available for potential necessary maintenance, repair or replacement, as the case may be.

We emphasize that the tank shall not be connected to power supply if flammable liquids (gasoline, stain cleaner) or gases, etc., are handled in its proximity.



If water is strongly calcareous we recommend that any of the common decalcifying devices was installed with the appliance, or that the thermostat was set to the minimum operating temperature of 60°C. For proper operation, drinkable water of adequate quality shall be used. To avoid potential sediments we recommend that the device was installed together with a water filter.

2.2 WALL MOUNTING



Prior to mounting, check the loading capacity of the wall and, depending on the type of masonry, choose a suitable anchorage material, or reinforce the wall, if needed. The NTR/Z water heater shall only be mounted in vertical position so that the lower edge of the tank was placed at least 600 mm above the floor. In combined tanks, elbows have to be attached to the heating water inlet and outlet and, by turning them, the mounting either from the right or from the left has to be determined (Figure 14). With regard to various types of bearing masonry and wide range of special anchorage material available at the market, we do not provide the tanks with that material. The anchorage system has to be selected individually, depending on the conditions. We recommend an authorised company perform mounting on the wall and anchorage, or discuss the anchorage with a professional.



If hot water tank is mounted in a **tight, smaller space**, or in an intermediate ceiling, etc., you have to make sure that the connecting side of the appliance (connections to water supply, area for electric plugging) remained accessible and no heat accumulation occurs. Free space of up to **600 mm** from the bottom edge of the tank has to be available under the tank.

Mount the anchors by the dimensional drawing (Figure 16) in a **450 mm** spacing. Double check the torque of the suspension bolts on the heater and suspend the heater. Using the detent support in the bottom part of the heater make sure it runs in parallel with the wall (Figure 10) in 80-125 L heaters (Figure 1, Figure 4).




Figure 11

2.3 PLUMBING FIXTURE



Connecting tanks to plumbing fixtures is shown in (Figure 12, Figure 13, Figure 14, Figure 15). For potential disconnection of the tank, utility water inlets and outlets must be provided with Js 3/4" screw coupling. If the hot utility water (HUW) distribution is equipped with circulation circuit, the reverse pipe is connected to the inlet identified as CIRCULATION. Types 100, 125, 160 NTR and 100, 125, 160 NTR / HV are equipped with a drain outlet. A "T" plumbing with a drain valve has to be mounted in type 200 and 250 NTR(R) on the HSW inlet. The tank shall be equipped with a safety valve to ensure the operation. The safety valve is mounted on the cold water inlet identified with a blue ring. We recommend that the hot water distribution from the heater was as short as possible to minimise heat losses. **Tanks must be provided with a discharge valve** mounted on the cold service water inlet into the heater for potential disassembly or repair.



Every hot utility water pressure tank shall be equipped with membrane spring loaded with safety valve. Safety valve shall be easily accessible, fitted as close as possible to the tank. The inlet pipes must have at least the same clearance as the safety valve. Safety valve is placed high enough to secure dripping water drain by gravity. We recommend mounting the safety valve onto a branch pipe. Easier exchange without the necessity of draining water from the tank. Safety valves with fixed pressure settings from the manufacturer are used for the assembly. The starting pressure of the safety valve must be identical to the maximum allowed pressure of the tank, and at least 20 % higher than is the maximum pressure in the water main (Table 10). If the water main pressure exceeds such value, a reduction valve must be added to the system. No closing armature may be mounted between the tank and the safety valve. During assembly, follow the guide provided by the safety equipment manufacturer.



It is necessary to check the safety valve each time before putting it into operation. It is checked by manual moving of the membrane from the seat, turning the make-and-break device button always in the direction of the arrow. After being turned, the button must click back into a notch. Proper function of the make-and-break device results in water draining through the safety valve outlet pipe. In regular operation, such a check needs to be carried out at least once a month, and after each shutdown of the tank longer than 5 days. Water may be dripping off the drain pipe of the safety valve; the pipe must be open into the air, pointed down; environment temperatures must not drop below zero. When draining the tank, use the recommended drain valve. First of all, close water inlet in the tank. Find necessary pressure values in the following table. For proper safety valve operation, a backflow valve shall be mounted on the inlet pipes, preventing spontaneous heater draining of the tank and hot water penetration back into the water main.


Required pressures (Table 10).

SAFETY VALVE STARTING PRESSURE (MPa)	ACCEPTABLE OPERATING OVER-PRESSURE OF THE WATER HEATER (MPa)	MAX COLD WATER PRESSURE IN PIPING (MPa)
0,6	0,6	up to 0.48
0,7	0,7	up to 0.56
1	1	up to 0.8

Table 10

CONNECTING A TANK TO A WATER AND HEATING SYSTEM

OKC 100 NTR, OKC125 NTR, OKC 160 NTR



- U - Closing valve
- P1 - Safety valve with backflow flap
- P2 - Safety valve for heating circuit
- V - Drain valve
- M - Manometer
- T - Three-way valve
- O - Air outlet valve

* Use of expansion tank is not a prerequisite of correct connection but just a possible design variant

OKC 200 NTR, OKC 250 NTR





Figure 12

OKC 200 NTRR, OKC 250 NTRR

Exchangers combined in a series



- U - Closing valve
- P1 - Safety valve with backflow flap
- P2 - Safety valve for heating circuit
- V - Drain valve
- M - Manometer
- T - Three-way valve
- O - Air outlet valve

* Use of expansion tank is not a prerequisite of correct connection but just a possible design variant

OKC 200 NTRR, OKC 250 NTRR

Two heating water sources




Figure 13

Examples of connection of the heater to a water mains and heating system

OKC 100 NTR/HV, OKC125 NTR/HV, OKC 160 NTR/HV





Figure 14

CONNECTING A TANK TO A WATER AND HEATING SYSTEM

OKC 80 -200 NTR/Z



- O - bleeder valve
- U - stop valve
- P1 – safety valve with reverse flap
- P2 - safety valve for heating circuit
- M – manometer
- Z - test valve
- V - drain valve

The water installation must follow and meet the requirements and regulations relevant in the country of use!

Figure 15

2.4 CONNECTION OF INDIRECT TANK TO HOT WATER SYSTEM



It is recommended to install stop valves on the heating water inlet and outlet (for possible dismantling of the heater). Valves should be as close as possible to the tank to minimise heat losses.



When the tank is connected to water supply system, hot water heating system or power supply, and after the safety valve is tested (accordingly with the manual attached to the valve), the heater can be put in operation. Before opening the power supply, the tank must be filled with water. The process of first heating must be executed by licensed professional who has to check it. Both the hot water outlet pipe and safety armature parts may be hot.

2.5 ELECTRICAL INSTALLATION

2.5.1 GENERAL INFORMATION FOR ELECTRICAL INSTALLATION




- Check the insertion of the thermostat sensor in the thermowell, the so-called insertion all the way.
- The tank can be connected to any hot water heating boiler up to the 50 kW power output. To adjust the distance from the wall, connect the wire of the external protective bonding!
- The tank is powered directly from boiler by control voltage 230 V/50 Hz.
- Elastic cable CYSY 4Cx0.75 can be used for cross connection.
- Connecting terminals are identified on the tank's terminal board.

2.5.2 ELECTRONIC THERMOSTAT WIRING METHODS

Wiring of tanks of the below types:

OKC 200 NTR, OKC 200 NTRR, OKC 250 NTRR, OKC160 NTR/HV



- there is voltage on terminal 2 if tank is heated
- there is voltage on terminal 1 if tank is not heated

Figure 16




The control panel accommodates a touch thermometer to check the water temperature, and a capillary thermostat knob to set the desired water temperature and two pilot lights: "green" = tank heated; "orange" = tank is getting heated.

Wiring of tanks of the below types:

OKC 80 NTR/Z, OKC 100 NTR/Z, OKC 125 NTR/Z, OKC 160 NTR/Z, OKC 200 NTR/Z

OKC 100 NTR, OKC 125 NTR, OKC 160 NTR, OKC 100 NTR/HV, OKC125 NTR/HV



- there is voltage on terminal 2 if tank is heated
- there is voltage on terminal 1 if tank is not heated

Figure 17



The control panel accommodates a capillary thermostat knob to set the desired water temperature and an orange pilot light that is on when the tank's heating is on.

2.6 FIRST COMMISSIONING



To connect the tank to water supply system, hot water heating system, power supply and, after testing the safety valve (accordingly with the manual attached to the valve), the tank can be put in operation. Before opening the power supply, the tank must be filled with water. The process of first heating must be executed by licensed professional who has to check it. Both the hot water outlet pipe and safety armature parts may be hot.



During the heating process the pressurised connection water that increases its volume due to heating must drip off the safety valve. In non-pressurised connection water drips off the overflow combination faucet. When heating is finished, the set temperature and the actual temperature of consumed water must be more-or-less the same. After connecting the heater to the water main and electrical power system, and after checking the safety valve (following the instructions attached to the valve), the heater can be put into operation.

Procedure of putting the heater into operation:

1. Check both water and electric installation; for combined tanks, check also the installation to the hot water heating system. Check proper placement of thermostat sensors. The sensors in the thermowell have to be inserted all the way.
2. Open the hot water valve on the combination faucet.
3. Open the cold water inlet valve to the tank.
4. Once water starts draining through the hot water valve, filling of the tank is completed and the valve can be closed.
5. In case of leakage (of flange lid), we recommend that the flange lid bolts are fastened.
6. Screw down the electric installation guard.
7. When heating utility water with heat energy from the hot water heating system, open the heating water inlet and outlet valves, or de-aerate the exchanger.
8. When commencing operation, flush the heater until the cloudiness in the water is gone.
9. Make sure to fill in properly the warranty certificate.

2.7 PUTTING OUT OF SERVICE, DISCHARGE



If the hot water tank is put out of service or is not used for longer time, it has to be emptied and disconnected from power supply at all poles. The switch for the supply lead or the fuse cut-outs have to be shut off.

In locations that are permanently exposed to frost, hot water tank shall be emptied prior to the beginning of the cold season, if the appliance is not used for several days, and if the power supply is disconnected.



Drainage of utility water shall be performed after closing the shut-off valve in the cold water supply piping (through the discharge valve for safety valve combination), and with simultaneous opening of all hot water valves of connected fittings. Hot water may outflow during the drainage! If there is a risk of frost it has to be considered that not only the water in the hot water heater and in the hot water piping may get frozen but also the water in the entire cold water supply piping. It is therefore advisable to drain all fittings and piping that carry water, up to the part where the house water meter is installed (connection of the house to water main) which is not jeopardised by frost. When the tank is to be used again, it has to be filled with water and one needs to make sure that the **water flowing out at the hot water valves did not contain any bubbles**.

2.8 INSPECTION, MAINTENANCE & CARE FOR THE APPLIANCE



During the heating process the water that increases its volume during the heating must drip off the safety valve outlet (in non-pressurised connection this water drips off the combination faucet valve). In full heating (about 65°C) the volumetric water gain is approx. 3% of the tank capacity. The function of the safety valve has to be checked regularly (based on the information contained in the attached safety valve manual). In common operation, such a check needs to be implemented at least once a month, and after each heater shutdown that exceeds 5 days.

Caution! In doing so, the cold water supply pipe and the connection fitting of the tank may get heated! If the hot water heater does not work, or if hot water is not withdrawn, no water shall drip off the safety valve. If water drips, then the pressure in the supply piping is either too high, or the safety valve is defective. Please call a specialised plumber immediately!



If water contains too many minerals, an expert has to come to remove the scale that forms inside the tank, as well as free sediments. This has to be performed after one or two years of operation. Repeated heating causes lime scale settling on the receptacle walls and mostly on the lid of the flange. Lime scale settling depends on hardness of heated water, its temperature and on the volume of hot water used.

We recommend checking and cleaning the tank from lime scale and eventual replacement of the anode rod after two years of operation. The anode life is theoretically calculated for two years of operation; however, it changes with water hardness and chemical composition in the place of use. Based on such an inspection, the next term of anode rod exchange may be determined. Have a company in charge of service affairs deal with the cleaning and exchanging of the anode.

When draining water from the tank, the combination faucet valve for hot water must be open, preventing the occurrence of under-pressure in the tank receptacle which would stop water from draining. Cleaning takes place through the hole in the flange by: draining the tank, dismantling the flange lid and cleaning the tank. A new sealing has to be used for re-fitting. Since the inside of the tank has special enamel the surface of which must not get in contact with the scale removing agent – do not work with a lime pump. Remove the calcium build-up with timber, and Hoover it or wipe it with a cloth. Then the system must be thoroughly flushed and the heating process is checked as at the first startup. Do not use any abrasive cleaning agents or dye thinners (such as cellulose thinner, trichlor, and the like) to clean the outer shell of the tank. For cleaning use a wet clout and add a few drops of liquid cleaning agent for household applications.

2.9 MOST FREQUENT FUNCTION FAILURES AND THEIR CAUSES

Other potential failures – Table 11.

FAILURE SYMPTOM	INDICATOR	SOLUTION
Temperature of water is not corresponding with the set value		<ul style="list-style-type: none"> Defective thermostat
Water is constantly dripping off the safety valve	<ul style="list-style-type: none"> LED is not on 	<ul style="list-style-type: none"> high input pressure defective safety valve

Table 11



Do not attempt to repair the failure yourselves. Seek either expert or service help. It does not take much for an expert to remove the defect. When organizing a repair, state the model designation and the serial number that is to be found on the power plate of your water heater.

3 OPERATION OF THERMOSTAT

3.1 SERVICING

3.1.1 OPERATING DEVICES OF THE TANK

Tank panel OKC NTR/Z - 200 L




Figure 18

Tank panel OKC NTR/Z - 80-160 L




Figure 19

Neither the thermostat, nor any other part of the control panel is a bearing part that could be used for any handling the heater.

The panel of the OKC NTR,R tanks of 200 to 250 L volumes and of the OKC NTR/HV tanks of 160 L volumes




Figure 20

The panel of the OKC NTR,R tanks of 100 to 160 L volumes and of the OKC NTR/HV tanks of 100 to 125 L volumes




Figure 21

3.1.2 TEMPERATURE SETTING

Water temperature is set by turning the thermostat knob. The desired symbol is set against the fixed point on the control panel (Figure 22 and Figure 23).




Figure 22




Figure 23

4 IMPORTANT NOTICES

4.1 INSTALLATION REGULATIONS

- Check and exchange the Mg anode regularly.
- **No closing armature may be mounted between the tank and the safety valve.**
- If the overpressure in the water main exceeds 0.6 MPa, a reduction valve must be mounted before the safety valve.
- All outlets of hot water must be equipped with a combination faucet.
- Prior to the first filling the tank with water we recommend that the receptacle's flange connection nuts are tightened.
- It is not allowed to handle the thermostat, aside from temperature resetting with a control button.
- All electric installation handling, setting, and regulation feature exchange, may only be implemented by a service company.
- If you don't use the heater (hot water tank) for longer than 24 hours, or if the facility with heater is unattended, close the cold water inlet to the heater.
- The heater (hot water tank) shall be used exclusively in accordance with the conditions specified on the performance plate and in the instructions for electric wiring.



Both the electric and water installation must follow and meet the requirements and regulations relevant in the country of use!

4.2 ACCESSORIES

G3/4" safety valve is packed with the product and the OKC 100, 125 NTR and OKC 100, 125, 160 NTR/ HV types are additionally equipped with a discharge valve. In the OKC NTR/Z types, the suspension elements and the temperature indicator are included in the packaging.

It is in your own interest to check the completeness of the accessories.

4.3 TRANSPORT & STORAGE INSTRUCTIONS

The appliance shall be transported and stored in a dry place, and protected from weather effects with a temperature ranging from -15 to +50°C. During loading and unloading, the instructions stated on the packaging shall be observed.



Due to transport and thermal dilatations, excessive enamel may fall off on the bottom of the receptacle in heaters with exchanger. This phenomenon is very common and has no impact on the quality and service life of the heater. Decisive is the enamel layer that remains on the receptacle. DZD has long-term experience with this phenomenon, and it is not a reason for claim.

4.4 DISPOSAL OF PACKAGING MATERIAL AND NON-FUNCTIONING PRODUCT

A service fee for providing return and recovery of packaging material has been paid for the packaging in which the product was delivered. The service fee was paid pursuant to Act No 477/2001 Coll., as amended, at EKO-KOM a.s. The client number of the company is F06020274. Take the water boiler packages to a waste disposal place determined by the town. When the operation terminates, disassemble and transport the discarded and unserviceable heater to a waste recycling centre (collecting yard), or contact the manufacturer.



3-10-2016